



Model No:- 3X3-03 Free-Way Switch

HH Coil Split (Outer Coils) 2V2T




Model No:- 3X3-03 Free-Way Switch

HH Phase & Single Coils 2V/2T




Model No:- 3X3-03 Free-Way Switch

HH Phase & Single Coils 2V/2T



Model No:- 3X3-03 Free-Way Switch

SS 2V/2T



Scheme No 168 : Last Updated June 2016

Model No:- 3X3-03 Free-Way Switch

HH Piezo 2V/2T

 \bigcirc


 \bigcirc



'Link' wires would normally be connected for series humbucker operation (typically these are North & South finish wires).


The pickup colour coding shown in this diagram does not represent any particular pickup manufacturer - please follow designations.

FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 209 : Last Updated March 2017

HH Coil Split 2V2T



Model No:- 3X3-03 Free-Way Switch