

www.freewayswitch.com

# Notes:-


Positions 1, 2 & 3 are standard neck/both/bridge humbucker settings, positions 4, 5 & 6 are like the middle positions of a 5-way selector.

SWITCH

As an alternative, connect both 'CA' to 'CB' to vol pot. (remove grd. connection to 'CB') this will select 3 x single coils in position 5 and the middle + outer humbucker coils in positions 4 and 6.

The colour coding or magnetic polarity shown here does not represent any particular pickup manufacturer - please follow key.

# FRONT VIEW OF PICKUPS AND SWITCH




Scheme No 010: Last Updated June 2013

Model No:- 3X3-03 Free-Way Switch

**HSH 1V/1T** 






# Notes:-

Positions 1, 2 & 3 are neck/both/bridge settings (where the humbucker is tapped in position 2). Positions 4, 5 & 6 are like the middle positions of a 5-way selector.


The colour coding or magnetic polarity shown here does not represent any particular pickup manufacturer - please follow key.

# FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 011: Last Updated June 2013






# Notes:-

Positions 1, 2 & 3 are neck/both/bridge settings (where the humbucker is tapped in position 2). Positions 4, 5 & 6 are like the middle positions of a 5-way selector.

The colour coding or magnetic polarity shown here does not represent any particular pickup manufacturer - please follow key.


# FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 036: Last Updated Dec 2013

Model No:- 3X3-03 Free-Way Switch

SSH 1V/1T



# FREE-WAY SWITCH


MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD

# Notes:-

Positions 1, 2 & 3 are standard neck/both/bridge humbucker settings, positions 4, 5 & 6 offer single coil combinations.

The colour coding or magnetic polarity shown here does not represent any particular pickup manufacturer - please follow key.

# FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 070: Last Updated June 2014

Model No:- 3X3-03 Free-Way Switch

**HSH 1V/1T** 

# REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.



# MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD


# Notes:-

Positions 1, 2 & 3 are standard neck/both/bridge settings; positions 4, 5 & 6 are like the middle positions of a 5-way selector.

Tone control is 'master' and works in all positions.

The pickup colour coding shown in this diagram does not represent any particular pickup manufacturer - please follow designations.

# FRONT VIEW OF PICKUPS AND SWITCH




Scheme No 077: Last Updated July 2014

# Ш NECK **3RIDG** MIDDL 'Ground' **Ground**' 'Hot' 'Hot' Grd To Bridge Any solder points shown in between B1 (CA O CB) B1) pads are meant to Tone Vol abridge both pads B2) (Sleeve) N1 3030-03 Note Vertical Orientation! (Tip)

Model No:- 3X3-03 Free-Way Switch

SSS Master Tone 1V/1T






# Notes:-


Positions 1, 2 & 3 are standard neck/both/bridge humbucker settings,

The colour coding or magnetic polarity shown here does not represent any particular pickup manufacturer - please follow key.

# FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 131: Last Updated Sept 2015






# Notes:-

Positions 1, 2 & 3 are standard neck/both/bridge humbucker settings,

The colour coding or magnetic polarity shown here does not represent any particular pickup manufacturer - please follow key.


# FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 132: Last Updated Sept 2015

Model No:- 3X3-03 Free-Way Switch

**HSH 1V/1T** 







Notes:-

The colour coding or magnetic polarity shown here does not represent any particular pickup manufacturer - please follow key.

# FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 148: Last Updated Jan 2016






Notes:-

The colour coding or magnetic polarity shown here does not represent any particular pickup manufacturer - please follow key.

# FRONT VIEW OF PICKUPS AND SWITCH



Scheme No 154: Last Updated Feb 2016